

# Sonic Chem Deep Clean

## SPECIALITY ALKALINE CLEANER

*High Performance cleaner for crockery, cutlery, glasses, silverware, pots, pans, kitchen equipment and food processing equipment*

- Removes pathogens
- Removes grime, animal proteins, fats, oils, blood and grease
- Economical – 1:1500 dilution ratio
- Rinses easily
- Leaves no streaks
- Non-toxic and non-tainting at use dilutions
- Completely soluble in hot and cold water in all proportions
- Good tolerance of hard water
- Surfactants used in this product are biodegradable according to criteria laid down in the detergents regulations 648/2004

### APPLICATION(S):

**Use to clean a wide variety of items in the Sonic Wash system**

- China
- Glasses
- Silverware
- Dining room ware
- Pots
- Pans
- Utensils
- Kitchen equipment
- Food processing equipment

## DIRECTIONS FOR USE:

1. Remove gross food soils and grease from the items to be cleaned using water jet, plastic brush or scouring pad.
2. Fill ultrasonic sink with diluted Sonic Chem Get Clean (dilution ratio 1:1500).
3. Put items to be cleaned in ultrasonic sink and run cleaning cycle. Handle knives and other sharp objects carefully.
4. Rinse items thoroughly with potable water.
5. Sanitise with Sonic Chem Final Rinse according to label directions.
6. Rinse items thoroughly with potable water.
7. Air dry on the draining board.

NOTE: Change the detergent solution every four hours and the sanitizing solution regularly to keep it clean and effective.

## SPECIFICATION:

<b>Composition</b>	: A blend of anionic, non-ionic and amphoteric surface-active agents
<b>Appearance</b>	: Green liquid
<b>Odour</b>	: Lemon/citrus
<b>Density at 20°C</b>	: 1.10 kg/l
<b>pH value</b>	: 10 typical
<b>Miscibility</b>	: Miscible with water in all proportions
<b>Pack size</b>	: 5 litres
<b>Code</b>	: DC5L

*The information contained in this Product Information Sheet is believed to be accurate, but customers are advised to ensure that the product is suitable for their own purpose before they use it. Please ensure your employees read and understand the product label and safety data sheet before using this product. The label contains directions for use and both the label and SDS contain hazard warnings, precautionary statements and first aid procedure. SDSs are available on line at [www.sonic-wash.com/sonic-chem](http://www.sonic-wash.com/sonic-chem) or by contacting the company.*

Ultrasonic Products International, Abacus House, 33 Gutter Lane, London, EC2V 8AR, United Kingdom.

Email: [enquiries@sonic-wash.com](mailto:enquiries@sonic-wash.com) website: [www.sonic-wash.com](http://www.sonic-wash.com)

**Sonic Chem Deep Clean PIS**

**Issue 3**

**05 Mar 2014**